

SAFE DIGGING ROADMAP

PLAN

Allow time in your plans for the 811 system to function properly. Become familiar with the law: KRS 367.4901-367.4917



NOTIFY 811

Call 811 or visit: KENTUCKY811.ORG



CALL NON-MEMBERS

All utilities are not required to be a member of the 811 system in Kentucky. Each excavator must contact non-members directly.



WAIT

Wait two (2) working days excluding the day the request was made. Working day = 12:01 AM to Midnight excluding weekends and holidays.



POSITIVE RESPONSE

Kentucky law requires all utility operators to provide a status or an update of their response to your locate request.



LOCATE

Each member utility operator will respond and mark their facilities using the appropriate color based on the APWA Color Code Standard.



VERIFY

Inspect your worksite. Look for evidence of an unmarked utility facility. Call 811 again if necessary.



RESPECT

Respect the markings and observe the 24" tolerance zone that is measured from each side of the facility



DIG WITH CARE

Follow safe digging practices. Pothe and expose all marked utilities that are near your excavation site.



REPEAT

Repeat this process EVERY time you dig!

